



PART NUMBER	MODEL/TYPE	EQUIPMENT DESCRIPTION	MANUFACTURER
AK-350	AK-350	Altitude Encoder	Ameri-King Corporation
1C338	1C338	Century IIB & Autocontrol IIIB	Century Flight Systems
1C338-3	1C338-3	Century IIB & Autocontrol IIIB	Century Flight Systems
1C338-3-24	1C338-3-24	Century IIB & Autocontrol IIIB	Century Flight Systems
1C385	1C385	Century IIB & Autocontrol IIIB	Century Flight Systems
1C388	1C388	Radio Coupler	Century Flight Systems
1C388-2	1C388-2	Radio Coupler	Century Flight Systems
1C388-3	1C388-3	Radio Coupler	Century Flight Systems
1C388-M	1C388-M	Radio Coupler	Century Flight Systems
1C388-MC	1C388-MC	Radio Coupler	Century Flight Systems
1C388-P	1C388-P	Radio Coupler	Century Flight Systems
1C404	1C404	Century III Console	Century Flight Systems
1C404-1	1C404-1	Century III Console	Century Flight Systems
1C407	1C407	Altitude Hold	Century Flight Systems
1C493	1C493	Glideslope Coupler	Century Flight Systems
1C493R	1C493R	Glideslope Coupler	Century Flight Systems
1C497-1	1C497-1	Programmer	Century Flight Systems
1C497-6	1C497-6	Programmer	Century Flight Systems
1C497-8	1C497-8	Programmer	Century Flight Systems
1C515	1C515	Amplifier	Century Flight Systems
1C515-1	1C515-1	Amplifier	Century Flight Systems
1C515-2	1C515-2	Amplifier	Century Flight Systems
1C515-3	1C515-3	Amplifier	Century Flight Systems
1C515-4	1C515-4	Amplifier	Century Flight Systems
1C515-5	1C515-5	Amplifier	Century Flight Systems
1C535	1C535	Altitude Hold	Century Flight Systems
1C535	1C535	Altitude Hold	Century Flight Systems
1C535-1	1C535-1	Altitude Hold	Century Flight Systems
1C709	1C709	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-1	1C709-1	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-10	1C709-10	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-11	1C709-11	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-12	1C709-12	Electronic Pitch Trim Amplifier	Century Flight Systems



1C709-13	1C709-13	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-14	1C709-14	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-15	1C709-15	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-16	1C709-16	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-17	1C709-17	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-18	1C709-18	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-19	1C709-19	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-2	1C709-2	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-20	1C709-20	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-21	1C709-21	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-22	1C709-22	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-23	1C709-23	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-24	1C709-24	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-25	1C709-25	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-26	1C709-26	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-27	1C709-27	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-28	1C709-28	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-29	1C709-29	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-3	1C709-3	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-30	1C709-30	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-31	1C709-31	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-32	1C709-32	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-4	1C709-4	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-5	1C709-5	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-6	1C709-6	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-7	1C709-7	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-8	1C709-8	Electronic Pitch Trim Amplifier	Century Flight Systems
1C709-9	1C709-9	Electronic Pitch Trim Amplifier	Century Flight Systems
1D720	1D720	Century III Console	Century Flight Systems
1C930	1C930	Adaptor	Century Flight Systems
Century II	Century II	Autopilot System	Century Flight Systems
Century IIB	Century IIB	Autopilot System	Century Flight Systems
Century III	Century III	Autopilot System	Century Flight Systems
010-00230-00	GTX330	Mode S Transponder	Garmin



010-00230-01	GTX330	Mode S Transponder	Garmin
010-00230-20	GTX330	Mode S Transponder	Garmin
010-00230-21	GTX330	Mode S Transponder	Garmin
010-00293-00	GTX330D	Mode S Transponder	Garmin
010-00293-01	GTX330D	Mode S Transponder	Garmin
010-00293-20	GTX330D	Mode S Transponder	Garmin
010-00293-21	GTX330D	Mode S Transponder	Garmin
011-00259-10	GTX320	ATC Transponder	Garmin
011-00455-00	GTX330	ATC Transponder	Garmin
011-00455-10	GTX330D	ATC Transponder	Garmin
011-00455-20	GTX330	ATC Transponder	Garmin
011-00455-30	GTX330D	ATC Transponder	Garmin
011-00490-00	GTX327	ATC Transponder	Garmin
011-00026-00	GPS-100 Series	GPS Nav	Garmin
011-00412-xxxx	GNS-400 Series	GPS Nav/Comm	Garmin
011-00419-xxxx	GNS-500 Series	GPS Nav/Comm	Garmin
060-00013-0001	KSG-105	Slaved Directional Gyro	Honeywell Inc. (Bendix/King)
060-00015-0000	KG-102A	Directional Gyro	Honeywell Inc. (Bendix/King)
060-00015-0001	KG-102A	Directional Gyro	Honeywell Inc. (Bendix/King)
060-00024-0000	KRG-331	Rate Gyro	Honeywell Inc. (Bendix/King)
064-01019-0000	KY-196	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0001	KY-196E	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0002	KY-196	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0005	KY-196	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0006	KY-196E	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0007	KY-196	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0010	KY-196	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0011	KY-196E	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0012	KY-196	VHF Comm	Honeywell Inc. (Bendix/King)
064-01019-0020	KY-196	VHF Comm	Honeywell Inc. (Bendix/King)
064-01021-0000	KY-197	VHF Comm	Honeywell Inc. (Bendix/King)
064-01021-0001	KY-197E	VHF Comm	Honeywell Inc. (Bendix/King)
064-01021-0005	KY-197	VHF Comm	Honeywell Inc. (Bendix/King)
064-01021-0006	KY-197E	VHF Comm	Honeywell Inc. (Bendix/King)



064-01021-0010	KY-197	VHF Comm	Honeywell Inc. (Bendix/King)
064-01021-0011	KY-197E	VHF Comm	Honeywell Inc. (Bendix/King)
064-01021-0020	KY-197	VHF Comm	Honeywell Inc. (Bendix/King)
064-01051-0010	KY-97A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01051-0030	KY-97A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01051-0050	KY-97A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01051-0051	KY-97A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01051-0060	KY-97A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01051-0061	KY-97A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01051-0070	KY-97A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01052-0010	KY-96A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01052-0030	KY-96A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01052-0050	KY-96A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01052-0051	KY-96A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01052-0060	KY-96A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01052-0061	KY-96A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01052-0070	KY-96A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01053-0030	KY-197A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01053-0031	KY-197A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01053-0032	KY-197A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01053-0060	KY-197A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01054-0030	KY-196A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01054-0031	KY-196A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01054-0032	KY-196A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01054-0050	KY-196A	VHF Comm	Honeywell Inc. (Bendix/King)
064-01054-0060	KY-196A	VHF Comm	Honeywell Inc. (Bendix/King)
066-01021-0000	KR-21	MKR Rx	Honeywell Inc. (Bendix/King)
066-01021-0001	KR-21	MKR Rx	Honeywell Inc. (Bendix/King)
066-01021-0002	KR-21	MKR Rx	Honeywell Inc. (Bendix/King)
066-01023-0000	KR-85	ADF Receiver	Honeywell Inc. (Bendix/King)
066-01024-0000	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0001	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0002	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0003	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)



066-01024-0004	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0005	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0006	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0007	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0008	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0009	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0010	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0011	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0012	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0013	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0014	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0015	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01024-0016	KMA-20	Audio Panel	Honeywell Inc. (Bendix/King)
066-01033-0000	KN-73	Glideslope RX Converter	Honeywell Inc. (Bendix/King)
066-01034-0000	KT-76	ATC Transponder	Honeywell Inc. (Bendix/King)
066-01034-0001	KT-76	ATC Transponder	Honeywell Inc. (Bendix/King)
066-01034-0002	KT-78	ATC Transponder	Honeywell Inc. (Bendix/King)
066-01034-0003	KT-78	ATC Transponder	Honeywell Inc. (Bendix/King)
066-01038-0000	KR-86	ADF Receiver	Honeywell Inc. (Bendix/King)
066-01038-0010	KR-86	ADF Receiver	Honeywell Inc. (Bendix/King)
066-01053-0000	KT-79	ATC Transponder	Honeywell Inc. (Bendix/King)
066-01055-0000	KMA-24	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0001	KMA-24	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0002	KMA-24	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0003	KMA-24	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0050	KMA-24H-50	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0051	KMA-24H-51	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0052	KMA-24H-52	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0053	KMA-24H-53	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0054	KMA-24H-54	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0070	KMA-24H-70	Audio Panel	Honeywell Inc. (Bendix/King)
066-01055-0071	KMA-24H-71	Audio Panel	Honeywell Inc. (Bendix/King)
066-01062-0000	KT-76A	ATCRBS Transponder	Honeywell Inc. (Bendix/King)
066-01062-0001	KT-78A	ATCRBS Transponder	Honeywell Inc. (Bendix/King)



066-01062-0002	KT-76A	ATCRBS Transponder	Honeywell Inc. (Bendix/King)
066-01062-0010	KT-76A	ATCRBS Transponder	Honeywell Inc. (Bendix/King)
066-01064-0000	KN-62	DME	Honeywell Inc. (Bendix/King)
066-01066-0000	KDM-706	DME	Honeywell Inc. (Bendix/King)
066-01066-0001	KDM-706	DME	Honeywell Inc. (Bendix/King)
066-01066-0002	KDM-706	DME	Honeywell Inc. (Bendix/King)
066-01066-0041	KDM-706	DME	Honeywell Inc. (Bendix/King)
066-01067-0000	KN-53	NAV Receiver	Honeywell Inc. (Bendix/King)
066-01067-0001	KN-53	NAV Receiver	Honeywell Inc. (Bendix/King)
066-01067-0002	KN-53	NAV Receiver	Honeywell Inc. (Bendix/King)
066-01067-0003	KN-53	NAV Receiver	Honeywell Inc. (Bendix/King)
066-01067-0004	KN-53	NAV Receiver	Honeywell Inc. (Bendix/King)
066-01067-0005	KN-53	NAV Receiver	Honeywell Inc. (Bendix/King)
066-01067-0010	KN-53	NAV Receiver	Honeywell Inc. (Bendix/King)
066-01068-0000	KN-62A	DME	Honeywell Inc. (Bendix/King)
066-01068-0001	KN-62A	DME	Honeywell Inc. (Bendix/King)
066-01068-0002	KN-62A	DME	Honeywell Inc. (Bendix/King)
066-01068-0003	KN-62A	DME	Honeywell Inc. (Bendix/King)
066-01068-0004	KN-62A	DME	Honeywell Inc. (Bendix/King)
066-01069-0000	KDI-572	DME IND	Honeywell Inc. (Bendix/King)
066-01069-0001	KDI-572	DME IND	Honeywell Inc. (Bendix/King)
066-01069-0002	KDI-573	DME IND	Honeywell Inc. (Bendix/King)
066-01069-0003	KDI-573	DME IND	Honeywell Inc. (Bendix/King)
066-01069-0004	KDI-574	DME IND	Honeywell Inc. (Bendix/King)
066-01069-0005	KDI-574	DME IND	Honeywell Inc. (Bendix/King)
066-01070-0000	KN-63	DME	Honeywell Inc. (Bendix/King)
066-01070-0001	KN-63	DME	Honeywell Inc. (Bendix/King)
066-01071-0000	KXP-756	ATC Transponder	Honeywell Inc. (Bendix/King)
066-01072-0000	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0001	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0002	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0003	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0004	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0005	KR-87	ADF RX	Honeywell Inc. (Bendix/King)



066-01072-0006	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0007	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0014	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0015	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01072-0017	KR-87	ADF RX	Honeywell Inc. (Bendix/King)
066-01088-0000	KN-64	DME	Honeywell Inc. (Bendix/King)
066-01088-0001	KN-64	DME	Honeywell Inc. (Bendix/King)
066-01141-5101	KT-71	ATCRBS Transponder	Honeywell Inc. (Bendix/King)
066-01141-5201	KT-71	ATCRBS Transponder	Honeywell Inc. (Bendix/King)
066-01141-6101	KT-71	ATCRBS Transponder	Honeywell Inc. (Bendix/King)
066-01156-0101	KT-76C	ATCRBS Transponder	Honeywell Inc. (Bendix/King)
066-01164-0101	KT-73	Mode S Transponder	Honeywell Inc. (Bendix/King)
066-03008-0002	KI-201C	VOR/LOC Indicator	Honeywell Inc. (Bendix/King)
066-03017-0000	KI-225	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03017-0001	KI-225	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03017-0002	KI-225	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03017-0003	KI-225	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03017-0004	KI-225	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03018-0000	KI-265	DME Indicator	Honeywell Inc. (Bendix/King)
066-03021-0000	KI-226	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03025-0000	KI-213	VOR/LOC Indicator	Honeywell Inc. (Bendix/King)
066-03025-0001	KI-214	VOR/LOC Indicator	Honeywell Inc. (Bendix/King)
066-03032-0000	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0001	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0002	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0003	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0004	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0005	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0006	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0007	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0008	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0009	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0010	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0011	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)



066-03032-0012	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0013	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0014	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0015	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0016	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0017	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0018	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0019	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0020	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03032-0021	KDI-571	DME Indicator	Honeywell Inc. (Bendix/King)
066-03034-0000	KI-203	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0001	KI-203	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0002	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0003	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0004	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0005	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0006	KI-207	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0007	KI-202	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0008	KI-202	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0009	KI-202	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0010	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0011	KI-202	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0012	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0013	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0014	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0015	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0016	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0017	KI-207	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0018	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0019	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0020	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0021	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0022	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0023	KI-204	NAV Indicator	Honeywell Inc. (Bendix/King)



066-03034-0024	KI-206	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0025	KI-207	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03034-0026	KI-202	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03038-0000	KI-229	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03038-0001	KI-229	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03042-0000	KNI-581	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03042-0001	KNI-581	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03042-0002	KNI-581	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03042-0003	KNI-581	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03046-0000	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0001	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0002	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0003	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0004	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0005	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0006	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0007	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0008	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0009	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0010	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0011	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0012	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03046-0013	KI-525A	H-S-I	Honeywell Inc. (Bendix/King)
066-03047-0000	KI-266	DME Indicator	Honeywell Inc. (Bendix/King)
066-03047-0001	KI-266	DME Indicator	Honeywell Inc. (Bendix/King)
066-03056-0000	KI-208	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03056-0001	KI-209	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03056-0002	KI-208	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03056-0003	KI-209	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03056-0010	KI-208A	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03056-0011	KI-209A	NAV Indicator	Honeywell Inc. (Bendix/King)
066-03059-0000	KI-228	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03059-0001	KI-228	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03060-0000	KNI-582	RMI Indicator	Honeywell Inc. (Bendix/King)



066-03060-0001	KNI-582	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03060-0002	KNI-582	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03060-0003	KNI-582	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03060-0004	KNI-582	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03060-0005	KNI-582	RMI Indicator	Honeywell Inc. (Bendix/King)
066-03063-0000	KI-227	ADF Indicator	Honeywell Inc. (Bendix/King)
066-03063-0001	KI-227	ADF Indicator	Honeywell Inc. (Bendix/King)
066-04004-0000	KN-77	VOR/LOC Converter	Honeywell Inc. (Bendix/King)
066-04008-0000	KNS-80	RNAV/DME/GS Rx	Honeywell Inc. (Bendix/King)
066-04008-0001	KNS-80	RNAV/DME/GS Rx	Honeywell Inc. (Bendix/King)
066-04008-0002	KNS-80	RNAV/DME/GS Rx	Honeywell Inc. (Bendix/King)
066-04008-0003	KNS-80	RNAV/DME/GS Rx	Honeywell Inc. (Bendix/King)
066-04009-0000	KN-72	VOR/LOC Converter	Honeywell Inc. (Bendix/King)
066-04010-0000	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0001	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0002	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0003	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0004	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0010	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0011	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0012	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0013	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0014	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0015	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0016	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0017	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0018	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0019	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0020	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0021	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0030	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0031	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0032	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0033	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)



066-04010-0034	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0035	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0036	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0037	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0038	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0039	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0040	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0060	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0061	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0062	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0063	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0064	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0065	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0066	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0067	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0069	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0070	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0071	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0080	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0081	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0082	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0083	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0084	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0085	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0086	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0087	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0088	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0089	KNS-81	Area Nav Computer	Honeywell Inc. (Bendix/King)
066-04010-0090	KNS-81	R-Nav	Honeywell Inc. (Bendix/King)
069-01010-0003	KI-212	VOR/LOC Indicator	Honeywell Inc. (Bendix/King)
069-01010-0004	KI-211C	VOR/LOC Indicator	Honeywell Inc. (Bendix/King)
069-01016-0000	KX-175	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01017-0000	KX-170A	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01018-0000	KY-195	COMM Tx	Honeywell Inc. (Bendix/King)



069-01019-0000	KX-175B	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01019-0001	KX-175B	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01019-0005	KX-175B	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01020-0000	KX-170B	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01021-0000	KY-195B	COMM	Honeywell Inc. (Bendix/King)
069-01024-0000	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0001	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0002	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0003	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0004	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0005	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0006	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0007	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0008	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0009	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0010	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0011	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0012	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0013	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0020	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0030	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0031	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0032	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0033	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0034	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0035	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0036	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0037	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0038	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0039	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0040	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0041	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0042	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01024-0043	KX-155	NAV/COMM	Honeywell Inc. (Bendix/King)



069-01025-0000	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0001	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0002	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0003	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0004	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0005	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0006	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0007	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0020	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0021	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0022	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0023	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0024	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0025	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0026	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01025-0027	KX-165	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01028-0101	KX-125	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01032-0101	KX-155A	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01032-0201	KX-155A	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01033-0101	KX-165A	NAV/COMM	Honeywell Inc. (Bendix/King)
069-01033-0201	KX-165A	NAV/COMM	Honeywell Inc. (Bendix/King)
071-00003-0000	KA-40	Remote Marker Lights	Honeywell Inc. (Bendix/King)
071-00017-0000	KA-57	Autopilot Adapter	Honeywell Inc. (Bendix/King)
071-01041-0001	KA-39	Voltage Converter	Honeywell Inc. (Bendix/King)
071-01041-0001	KA-39	Voltage Converter	Honeywell Inc. (Bendix/King)
071-01043-0000	KFS-570B	ATC Transponder Frequency Selector	Honeywell Inc. (Bendix/King)
071-01043-0001	KFS-570B	ATC Transponder Frequency Selector	Honeywell Inc. (Bendix/King)
071-01052-0000	KMT-112	Flux Detector	Honeywell Inc. (Bendix/King)
071-01053-0001	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01053-0002	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01053-0003	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01053-0004	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01053-0005	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01053-0006	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)



071-01053-0007	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01053-0008	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01053-0009	KA-51A	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01055-0000	KA-52	Autopilot Adapter	Honeywell Inc. (Bendix/King)
071-01076-0000	KDA-697	RMI Adapter	Honeywell Inc. (Bendix/King)
071-01133-0000	KA-42B	ADF Loop Antenna	Honeywell Inc. (Bendix/King)
071-01196-0000	KA-44	ADF Combined Antenna	Honeywell Inc. (Bendix/King)
071-01217-0000	KDA-692	RMI/ADF Adapter	Honeywell Inc. (Bendix/King)
071-01217-0001	KDA-692	RMI/ADF Adapter	Honeywell Inc. (Bendix/King)
071-01234-0000	KA-44B	ADF Combined Antenna	Honeywell Inc. (Bendix/King)
071-01234-0001	KA-44B	ADF Combined Antenna	Honeywell Inc. (Bendix/King)
071-01234-0002	KA-44B	ADF Combined Antenna	Honeywell Inc. (Bendix/King)
071-01242-0000	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0001	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0002	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0003	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0004	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0005	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0006	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0007	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0008	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0009	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0010	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0011	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0012	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0013	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
071-01242-0014	KA-51B	Slaving Accessory	Honeywell Inc. (Bendix/King)
4000256-8501	FC-813A	Flight Controller	Honeywell Inc. (Bendix/King)
4000256-8502	FC-813A	Flight Controller	Honeywell Inc. (Bendix/King)
4000256-8503	FC-813B	Flight Controller	Honeywell Inc. (Bendix/King)
4000256-8504	FC-813B	Flight Controller	Honeywell Inc. (Bendix/King)
4000256-8505	FC-813C	Flight Controller	Honeywell Inc. (Bendix/King)
4000256-8506	FC-813D	Flight Controller	Honeywell Inc. (Bendix/King)
4000256-8507	FC-813E	Flight Controller	Honeywell Inc. (Bendix/King)



4000256-8508	FC-813F	Flight Controller	Honeywell Inc. (Bendix/King)
4000288-8501	CA-814A	Computer Amplifier	Honeywell Inc. (Bendix/King)
4000288-8502	CA-814A	Computer Amplifier	Honeywell Inc. (Bendix/King)
4000288-8504	CA-814A	Computer Amplifier	Honeywell Inc. (Bendix/King)
4000288-8505	CA-814A	Computer Amplifier	Honeywell Inc. (Bendix/King)
4000288-8506	CA-814B	Computer Amplifier	Honeywell Inc. (Bendix/King)
4000289-8501	PS-815A	Power Supply	Honeywell Inc. (Bendix/King)
4000289-8502	PS-815B	Power Supply	Honeywell Inc. (Bendix/King)
4000289-8503	PS-815A	Power Supply	Honeywell Inc. (Bendix/King)
4000289-8504	PS-815B	Power Supply	Honeywell Inc. (Bendix/King)
4000289-8505	PS-815V	Power Supply	Honeywell Inc. (Bendix/King)
4000290-8503	SA-816A	Roll Servo	Honeywell Inc. (Bendix/King)
4000290-8504	SA-816B	Roll Servo	Honeywell Inc. (Bendix/King)
4000290-8505	SA-816A	Roll Servo	Honeywell Inc. (Bendix/King)
4000290-8506	SA-816B	Roll Servo	Honeywell Inc. (Bendix/King)
4000290-8507	SA-816C	Roll Servo	Honeywell Inc. (Bendix/King)
4000290-8508	SA-816D	Roll Servo	Honeywell Inc. (Bendix/King)
4000291-8502	SE-816A	Pitch Servo	Honeywell Inc. (Bendix/King)
4000291-8503	SE-816A	Pitch Servo	Honeywell Inc. (Bendix/King)
4000291-8504	SE-816B	Pitch Servo	Honeywell Inc. (Bendix/King)
4000292-8503	ST-816A	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8504	ST-816B	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8505	ST-816C	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8506	ST-816D	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8507	ST-816A	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8508	ST-816B	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8509	ST-816C	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8510	ST-816D	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8511	ST-816E	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000292-8517	ST-816L	Pitch Trim Servo	Honeywell Inc. (Bendix/King)
4000293-8501	PS-819A	Power Supply	Honeywell Inc. (Bendix/King)
4000293-8502	PS-819B	Power Supply	Honeywell Inc. (Bendix/King)
4000293-8503	PS-819A	Power Supply	Honeywell Inc. (Bendix/King)
4000293-8504	PS-819B	Power Supply	Honeywell Inc. (Bendix/King)



4000293-8505	PS-819V	Power Supply	Honeywell Inc. (Bendix/King)
4000315-8501	FC-823A	Flight Controller	Honeywell Inc. (Bendix/King)
4000315-8502	FC-823A	Flight Controller	Honeywell Inc. (Bendix/King)
4000315-8504	FC-823E	Flight Controller	Honeywell Inc. (Bendix/King)
4000317-8501	FC-823B	Flight Controller	Honeywell Inc. (Bendix/King)
4000317-8502	FC-823B	Flight Controller	Honeywell Inc. (Bendix/King)
4000317-8504	FC-823F	Flight Controller	Honeywell Inc. (Bendix/King)
4000393-0101	201F	ADF Receiver	Honeywell Inc. (Bendix/King)
ADF-T12D	201F	ADF Receiver	Honeywell Inc. (Bendix/King)
KDA-692	071-01217-0000	RMI/ADF Adapter	Honeywell Inc. (Bendix/King)
KDA-692	071-01217-0001	RMI/ADF Adapter	Honeywell Inc. (Bendix/King)
MX-11		VHF Comm Replacement	Michel
MX-170B		VHF Nav/Comm Replacement	Michel
01212-0101	DME-195	DME	Narco Avionics
01254-0101	CP-135W	Audio Panel/Marker Rx	Narco Avionics
01254-0102	CP-135	Audio Panel/Marker Rx	Narco Avionics
01254-0103	CP-136W	Audio Panel/Marker Rx	Narco Avionics
01254-0104	CP-136	Audio Panel/Marker Rx	Narco Avionics
01258-0101L	AT-150	ATC Transponder	Narco Avionics
01258-0102L	AT-150	ATC Transponder	Narco Avionics
01258-0103L	AT-150	ATC Transponder	Narco Avionics
01380-0101	DME-890	DME	Narco Avionics
01392-0107	MK-12D+	VHF NAV/COMM	Narco Avionics
01400-0101	ID-841	ADF Indicator	Narco Avionics
01401-0101	NA-841	ADF Antenna	Narco Avionics
01447-0103	AR-850	Altitude Reporter	Narco Avionics
03410-0302	ADF-841	ADF Receiver	Narco Avionics
	ADF-141	ADF RX	Narco Avionics
AT-50	AT-50	ATC Transponder Tx	Narco Avionics
AT-50A	AT-50A	ATC Transponder Tx	Narco Avionics
COM-120	COM-120	VHF Comm Tx	Narco Avionics
COM-810	COM-810	VHF Comm Tx	Narco Avionics
DME-190	DME-190	DME Transceiver	Narco Avionics
DME-190 TSO	DME-190 TSO	DME Transceiver	Narco Avionics



ID-824		VOR/LOC/IND	Narco Avionics
ID-825		VOR/ILS/IND	Narco Avionics
IDME-891		DME/ VOR/ILS/IND	Narco Avionics
IDME-895		DME/VOR/ILS/IND	Narco Avionics
MK-12D		VHF Nav/Comm	Narco Avionics
MK-12D Cessna		VHF Nav/Comm Replacement	Narco Avionics
MK-12E		VHF Nav/Comm	Narco Avionics
NAV-121		VOR/LOC/IND/RX	Narco Avionics
NAV-122		VOR/ILS/IND/RX	Narco Avionics
NCS-812		VHF Nav/Comm	Narco Avionics
AA97-402	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-403	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-403N	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-411	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-427	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-427NB	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-AAC	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-PAS	AA97 Series	Audio Controllers	Northern Airborne Technology
AA97-RAF	AA97 Series	Audio Controllers	Northern Airborne Technology
AMS43 Series	AMS43 Series	Single Channel Audio Controller	Northern Airborne Technology
NT 136 series		TX/RX	Northern Airborne Technology
AVDU-2640-02		VDU	Real-Time Vision Ltd
RCMP-1080-01-51		Control unit	Real-Time Vision Ltd
	R-546A	ADF RX	Sigma-Tek Cessna/ARC
	R-546B	ADF RX	Sigma-Tek Cessna/ARC
	R-546C	ADF RX	Sigma-Tek Cessna/ARC
	R-546D	ADF RX	Sigma-Tek Cessna/ARC
41240-0101	R-546E 300ADF	ADF RX	Sigma-Tek Cessna/ARC
41420-0014	RT-359A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41420-0028	RT-359A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41420-1114	RT-359A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41420-1128	RT-359A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41470-0014	RT-459A	ATC Transponder Rx/Tx	Sigma-Tek Inc.



41470-0028	RT-459A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41470-1014	RT-459A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41470-1028	RT-459A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41470-1114	RT-459A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
41470-1128	RT-459A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
42260-0028	RT-859A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
42260-1028	RT-859A	ATC Transponder Rx/Tx	Sigma-Tek Inc.
622-2078-001	VHF-251	VHF Comm Tx	S-Tec Avionics
622-2080-011	VIR-351	NAV Receiver	S-Tec Avionics
622-2084-001	GLS-350	Glideslope Receiver	S-Tec Avionics
622-2087-0XX	AMR-350	Audio/MKR Rx	S-Tec Avionics
622-2091-001	RCR-650	ADF Receiver	S-Tec Avionics
622-2091-002	RCR-650	ADF Receiver	S-Tec Avionics
622-2091-003	RCR-650	ADF Receiver	S-Tec Avionics
622-2091-004	RCR-650	ADF Receiver	S-Tec Avionics
622-2091-005	RCR-650	ADF Receiver	S-Tec Avionics
622-2091-006	RCR-650	ADF Receiver	S-Tec Avionics
622-2092-001	TDR-950	ATC Transponder Rx	S-Tec Avionics
622-2462-0XX	AMR-350H	Audio/MKR Rx	S-Tec Avionics
622-2536-001	IND-650	ADF Indicator	S-Tec Avionics
622-2609-001	ADA-650	ADF/RMI Adapter	S-Tec Avionics
622-3004-00X	TDR-950L	ATC Transponder Rx	S-Tec Avionics
622-3363-001	VHF-251E	VHF Comm Tx	S-Tec Avionics
622-3586-001	ANT-650A	ADF Antenna	S-Tec Avionics
622-3587-001	RCR-650A	ADF Receiver	S-Tec Avionics
622-3587-002	RCR-650A	ADF Receiver	S-Tec Avionics
622-3587-003	RCR-650A	ADF Receiver	S-Tec Avionics
622-3587-004	RCR-650A	ADF Receiver	S-Tec Avionics
622-3587-005	RCR-650A	ADF Receiver	S-Tec Avionics
622-3587-006	RCR-650A	ADF Receiver	S-Tec Avionics
622-3670-001	TCR-451	DME Transceiver	S-Tec Avionics
622-3671-001	IND-450	DME Indicator	S-Tec Avionics
622-3672-001	IND-451	DME Indicator	S-Tec Avionics
622-4480-001	IND-650A	ADF Indicator	S-Tec Avionics



622-5588-001	IND-450C	DME Indicator	S-Tec Avionics
	S-TEC 20	Auto pilot	S-Tec Avionics
	S-TEC 30	Auto pilot	S-Tec Avionics
	S-TEC 40	Auto pilot	S-Tec Avionics
	S-TEC 50	Auto pilot	S-Tec Avionics
	S-TEC 60-1	Auto pilot	S-Tec Avionics
	S-TEC 60-2	Auto pilot	S-Tec Avionics
0900-4099-01	AT 3000	Altitude Encoder	Terra by Trimble
D120-P2-T	KE-127	Altitude Digitizer	Transcal Industries Inc.